







Thule Rapid System Kit 1792

> Instructions

HONDA HR-V, 5-dr SUV, 15-

HONDA Vezel, 5-dr SUV, 14-




ISO 11154-E

141792
C.20151124
519-1792-01


Bring your life
thule.com




204 x1




206 x1



370 x1



371 x1



1366 x2



1367 x2






x1



x1

1

	X (scale)	X (mm)	X (inch)
HONDA HR-V, 5-dr SUV, 15-	40	1051	41 ³ / ₈
HONDA Vezel, 5-dr SUV, 14-	40	1051	41 ³ / ₈






	Y (scale)	Y (mm)	Y (inch)
HONDA HR-V, 5-dr SUV, 15-	38	1031	40 ⁵ / ₈
HONDA Vezel, 5-dr SUV, 14-	38	1031	40 ⁵ / ₈

2

HONDA HR-V, 5-dr SUV, 15-

HONDA Vezel, 5-dr SUV, 14-



3

	W (mm)	Z (mm)	W (inch)	Z (inch)
HONDA HR-V , 5-dr SUV, 15-	270	620	10 ⁵/₈	24 ³/₈
HONDA Vezel , 5-dr SUV, 14-	270	620	10 ⁵/₈	24 ³/₈

