

Kit 1427




TOYOTA Belta (Mk.II), 4-dr Sedan, 05– (JPN)

TOYOTA Vios (Mk.II), 4-dr Sedan, 05–

TOYOTA Vitz, 5-dr Hatchback, 05– (JPN)

TOYOTA Yaris (Mk.II), 4-dr Sedan, 05–

TOYOTA Yaris, 5-dr Hatchback, 05–



480R/754

x1

x4

x4

480

x1

x4




x4

750

x1

x4

x4

   x2  x2  x2  x4	  x2	  x2  x2  x4  x4	  x2  x2	  x2
---	---	--	---	---

Kit

745 x 2






860 x 2

23 x 1




24 x 1

228 x 1



x 1



3



1




2



X

TOYOTA Belta (Mk.II), 4-dr Sedan, 05- (JPN)	26,5
TOYOTA Vios (Mk.II), 4-dr Sedan, 05-	26,5
TOYOTA Vitz, 5-dr Hatchback, 05- (JPN)	28,5
TOYOTA Yaris (Mk.II), 4-dr Sedan, 05-	26,5
TOYOTA Yaris, 5-dr Hatchback, 05-	28,5

1



2




Y

TOYOTA Belta (Mk.II), 4-dr Sedan, 05- (JPN)	26
TOYOTA Vios (Mk.II), 4-dr Sedan, 05-	26
TOYOTA Vitz, 5-dr Hatchback, 05- (JPN)	24,5
TOYOTA Yaris (Mk.II), 4-dr Sedan, 05-	26
TOYOTA Yaris, 5-dr Hatchback, 05-	24,5



1




2



X inch X mm

TOYOTA Belta (Mk.II), 4-dr Sedan, 05- (JPN)	36 1/8"	916 mm
TOYOTA Vios (Mk.II), 4-dr Sedan, 05-	36 1/8"	916 mm
TOYOTA Vitz, 5-dr Hatchback, 05- (JPN)	36 7/8"	936 mm
TOYOTA Yaris (Mk.II), 4-dr Sedan, 05-	36 1/8"	916 mm
TOYOTA Yaris, 5-dr Hatchback, 05-	36 7/8"	936 mm

1



2



Y inch Y mm

TOYOTA Belta (Mk.II), 4-dr Sedan, 05- (JPN)	35 7/8"	911 mm
TOYOTA Vios (Mk.II), 4-dr Sedan, 05-	35 7/8"	911 mm
TOYOTA Vitz, 5-dr Hatchback, 05- (JPN)	35 1/4"	896 mm
TOYOTA Yaris (Mk.II), 4-dr Sedan, 05-	35 7/8"	911 mm
TOYOTA Yaris, 5-dr Hatchback, 05-	35 1/4"	896 mm

4








TOYOTA Belta (Mk.II), 4-dr Sedan, 05- (JPN)

TOYOTA Vios (Mk.II), 4-dr Sedan, 05-


TOYOTA Vitz, 5-dr Hatchback, 05- (JPN)

TOYOTA Yaris (Mk.II), 4-dr Sedan, 05-



TOYOTA Yaris, 5-dr Hatchback, 05-



5



	X mm	Y mm	X inch	Y inch
TOYOTA Belta (Mk.II), 4-dr Sedan, 05- (JPN)	190 mm	710 mm	7 1/4"	28"
TOYOTA Vios (Mk.II), 4-dr Sedan, 05-	190 mm	710 mm	7 1/4"	28"
TOYOTA Vitz, 5-dr Hatchback, 05- (JPN)	130 mm	710 mm	5 1/8"	28"
TOYOTA Yaris (Mk.II), 4-dr Sedan, 05-	190 mm	710 mm	7 1/4"	28"
TOYOTA Yaris, 5-dr Hatchback, 05-	130 mm	710 mm	5 1/8"	28"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ


6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		544 (x4)
		596 (x6)
		588 (x8)
NA		510 (x10)
EUR		452 (x12)
ASIA		