



Kit 1051

VOLKSWAGEN Bora, 4-dr Sedan, 99-04


VOLKSWAGEN Golf IV, 5-dr Hatchback, 98-03

VOLKSWAGEN Jetta, 5-dr Hatchback, 99–



480R
754



480












750




THULE[®]
SWEDEN

ISO 11154-E







3





754



750

1




2




X

VOLKSWAGEN Bora, 4-dr Sedan, 99-04	27
VOLKSWAGEN Golf IV, 5-dr Hatchback, 98-03	27
VOLKSWAGEN Jetta, 5-dr Hatchback, 99-	27

1



2



Y

VOLKSWAGEN Bora, 4-dr Sedan, 99-04	21
VOLKSWAGEN Golf IV, 5-dr Hatchback, 98-03	21
VOLKSWAGEN Jetta, 5-dr Hatchback, 99-	21




480R



480

1




2




X inch X mm

VOLKSWAGEN Bora, 4-dr Sedan, 99-04	36 1/4"	921 mm
VOLKSWAGEN Golf IV, 5-dr Hatchback, 98-03	36 1/4"	921 mm
VOLKSWAGEN Jetta, 5-dr Hatchback, 99-	36 1/4"	921 mm

1



2















Y inch Y mm








VOLKSWAGEN Bora, 4-dr Sedan, 99-04	33 7/8"	861 mm
VOLKSWAGEN Golf IV, 5-dr Hatchback, 98-03	33 7/8"	861 mm
VOLKSWAGEN Jetta, 5-dr Hatchback, 99-	33 7/8"	861 mm

4

VOLKSWAGEN Bora, 4-dr Sedan, 99-04
 VOLKSWAGEN Golf IV, 5-dr Hatchback, 98-03
 VOLKSWAGEN Jetta, 5-dr Hatchback, 99-



5



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754





480






750





i








i



i





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		