





Kit 1525

NISSAN Pixo, 5-dr Hatchback, 09–
SUZUKI Alto, 5-dr Hatchback, 09–



**480R
754**



480



750



480R/754

x1

x4

x4

480

x1

x4




x4

750

x1

x4

x4

  x2  x2  x2  x2  x4	 x2  x2	 x2  x2  x2  x4  x4	 x2  x2  x2	 x2  x2
--	--	---	--	--

Kit

975 x 2

978 x 2






296 x 1

297 x 1


298 x 1

299 x 1


4-way connector x 1



3




754




750



1




2




X	
NISSAN Pixo, 5-dr Hatchback, 09–	32
SUZUKI Alto, 5-dr Hatchback, 09–	32

1



2



Y	
NISSAN Pixo, 5-dr Hatchback, 09–	28,5
SUZUKI Alto, 5-dr Hatchback, 09–	28,5




480R



480

1




2



	X inch	X mm
NISSAN Pixo, 5-dr Hatchback, 09–	38 1/4"	971 mm
SUZUKI Alto, 5-dr Hatchback, 09–	38 1/4"	971 mm

1










2




	Y inch	Y mm
NISSAN Pixo, 5-dr Hatchback, 09–	36 7/8"	936 mm
SUZUKI Alto, 5-dr Hatchback, 09–	36 7/8"	936 mm

4



NISSAN Pixo, 5-dr Hatchback, 09–
SUZUKI Alto, 5-dr Hatchback, 09–



5



	X mm	Y mm	X inch	Y inch
NISSAN Pixo , 5-dr Hatchback, 09–	255 mm	700 mm	10 "	27 1/2 "
RENAULT Laguna II , 5-dr Estate, 03/2002-04, 05–	255 mm	700 mm	10 "	27 1/2 "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		