



Kit 1014

BMW 3-series Compact, 3-dr Coupe, 94-00


BMW 3-series, 4-dr Sedan, 91-97

BMW 3-series Touring, 5-dr Estate, 96-99



**480R
754**



480



750




THULE[®]
SWEDEN

ISO 11154-E






BMW 3-series Compact, 3-dr Coupe, 94-00

Max.
60kg/132 lbs



BMW 3-series, 4-dr Sedan, 91-97
BMW 3-series Touring, 5-dr Estate, 96-99


Max.
75kg/165 lbs




222 x 4



71 x 2



16 x 4








14 x 2




x 1



Kit



3




754




750

1




2



	X
BMW 3-series Compact, 3-dr Coupe, 94-00	26
BMW 3-series, 4-dr Sedan, 91-97	26,5
BMW 3-series Touring, 5-dr Estate, 96-99	26,5

1



2



	Y
BMW 3-series Compact, 3-dr Coupe, 94-00	28
BMW 3-series, 4-dr Sedan, 91-97	23
BMW 3-series Touring, 5-dr Estate, 96-99	22,5




480R



480

1




2




	X inch	X mm
BMW 3-series Compact, 3-dr Coupe, 94-00	35 $\frac{7}{8}$ "	911 mm
BMW 3-series, 4-dr Sedan, 91-97	36 $\frac{1}{8}$ "	916 mm
BMW 3-series Touring, 5-dr Estate, 96-99	36 $\frac{1}{8}$ "	916 mm

1




2



	Y inch	Y mm
BMW 3-series Compact, 3-dr Coupe, 94-00	36 $\frac{5}{8}$ "	931 mm
BMW 3-series, 4-dr Sedan, 91-97	34 $\frac{5}{8}$ "	881 mm
BMW 3-series Touring, 5-dr Estate, 96-99	34 $\frac{1}{2}$ "	876 mm














4

BMW 3-series Compact, 3-dr Coupe, 94-00




BMW 3-series, 4-dr Sedan, 91-97


BMW 3-series Touring, 5-dr Estate, 96-99



5






BMW 3-series Compact, 3-dr Coupe, 94-00



BMW 3-series, 4-dr Sedan, 91-97

BMW 3-series Touring, 5-dr Estate, 96-99



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte bagážníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754





480






750






i








i



i





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		