



Kit 1020


BMW 5-series, 4-dr Sedan, 96-00, 01-03

BMW 5-series, 5-dr Touring, 96-00, 01-03



**480R
754**



480



750



**Max.
75kg**
**Max.
165 lbs**

Kit XXXX
instructions

x1

x4

x4

x4

x4

480R/754

x1

x4

x4

x4

x4

480

x1

x4

x4

750

x2 x2 x2 x4	x2	x2 x2 x4 x4	x2 x2 x2	x2
----------------------	----	----------------------	----------------	----






73 x2

75 x2


15 x4

x1


Kit



3




754



750

1




2



	X
BMW 5-series, 4-dr Sedan, 96-00, 01-03	36,5
BMW 5-series, 5-dr Touring, 96-00, 01-03	34

1



2



	Y
BMW 5-series, 4-dr Sedan, 96-00, 01-03	33
BMW 5-series, 5-dr Touring, 96-00, 01-03	30,5




480R




480

1




2




	X inch	X mm
BMW 5-series, 4-dr Sedan, 96-00, 01-03	40"	1016 mm
BMW 5-series, 5-dr Touring, 96-00, 01-03	39"	991 mm

1



2















	Y inch	Y mm
BMW 5-series, 4-dr Sedan, 96-00, 01-03	39 5/8"	981 mm
BMW 5-series, 5-dr Touring, 96-00, 01-03	37 5/8"	956 mm


4

BMW 5-series, 4-dr Sedan, 96-00, 01-03




BMW 5-series, 5-dr Touring, 96-00, 01-03



5



	X mm	Y mm	X inch	Y inch
BMW 5-series, 4-dr Sedan, 96-00, 01-03	190 mm	690 mm	7 1/2"	27 1/8"
BMW 5-series, 5-dr Touring, 96-00, 01-03	480 mm	700 mm	18 7/8"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		544 (x4)
		596 (x6)
		588 (x8)
NA		510 (x10)
EUR		452 (x12)
ASIA		