









Kit 1064

TOYOTA HiLux Surf, 5-dr SUV, 96-03


TOYOTA 4 Runner, 5-dr SUV, 96-03




Kit



3





754



750



1



2




TOYOTA HiLux Surf, 5-dr SUV, 96-03
TOYOTA 4 Runner, 5-dr SUV, 96-03


X

32,5
32,5

1



2



TOYOTA HiLux Surf, 5-dr SUV, 96-03
TOYOTA 4 Runner, 5-dr SUV, 96-03

Y

32,5
32,5




480R




480

1



2



TOYOTA HiLux Surf, 5-dr SUV, 96-03
TOYOTA 4 Runner, 5-dr SUV, 96-03

X inch

X mm


38 3/8"

976 mm


38 3/8"

976 mm

1



2



TOYOTA HiLux Surf, 5-dr SUV, 96-03
TOYOTA 4 Runner, 5-dr SUV, 96-03

Y inch

Y mm

38 3/8"

976 mm














38 3/8"

976 mm


4

TOYOTA HiLux Surf, 5-dr SUV, 96-03




TOYOTA 4 Runner, 5-dr SUV, 96-03



5



	X mm	Y mm	X inch	Y inch
TOYOTA HiLux Surf, 5-dr SUV, 96-03	270 mm	700 mm	10 ⁵ / ₈ "	27 ¹ / ₂ "
TOYOTA 4 Runner, 5-dr SUV, 96-03	270 mm	700 mm	10 ⁵ / ₈ "	27 ¹ / ₂ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ






6





480R/754



480



750




i




1




2




i



1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		