



Kit 1165


TOYOTA Estima, 5-dr MPV, 00-02, 03-

TOYOTA Previa, 5-dr MPV, 00-02, 03-



480R
754



480





750



THULE[®]
SWEDEN






ISO 11154-E

The diagram illustrates the importance of instructions. It features a box on the left labeled "THULE" with a warning symbol (a triangle with an exclamation mark) and a plus sign next to it. To the right of the plus sign is a box labeled "Kit XXXX" with the word "instructions" written vertically on its side. This box also contains a warning symbol and a list of items: a bag, a box, a bag, a box, a bag, and a box. A person is shown on the right, reading a document, likely the instructions.




				
				
				
				
				
				
				
				
				
				
				
				
				
				
				
				
				
				

Parts list for step 10:


- Bracket (283) x 4
- Bracket (46) x 4
- Screw x 4
- Washer x 4
- Allen key x 1
- 4-way connector x 1




3



1




2




	X
TOYOTA Estima, 5-dr MPV, 00-02, 03-	34
TOYOTA Previa, 5-dr MPV, 00-02, 03-	34

1



2



	Y
TOYOTA Estima, 5-dr MPV, 00-02, 03-	31
TOYOTA Previa, 5-dr MPV, 00-02, 03-	31




480R




480

1




2




	X inch	X mm
TOYOTA Estima, 5-dr MPV, 00-02, 03-	39 "	991 mm
TOYOTA Previa, 5-dr MPV, 00-02, 03-	39 "	991 mm

1










2









	Y inch	Y mm
TOYOTA Estima, 5-dr MPV, 00-02, 03-	37 ⁷ / ₈ "	961 mm
TOYOTA Previa, 5-dr MPV, 00-02, 03-	37 ⁷ / ₈ "	961 mm





4



5



6



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6





480R/754



480




750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		