






Kit 1224






TOYOTA Camry, 4-dr Sedan, 92-96 (USA)





THULE[®]
SWEDEN

ISO 11154-E


Kit







TOYOTA Camry, 4-dr Sedan, 92-96 (USA)

X
31,5



TOYOTA Camry, 4-dr Sedan, 92-96 (USA)

Y
30,5





TOYOTA Camry, 4-dr Sedan, 92-96 (USA)

X inch

X mm

38 "

966 mm




TOYOTA Camry, 4-dr Sedan, 92-96 (USA)

Y inch

Y mm








37 5/8 "

956 mm




4




TOYOTA Camry, 4-dr Sedan, 92-96 (USA)



5



	X mm	Y mm	X inch	Y inch
TOYOTA Camry, 4-dr Sedan, 92-96 (USA)	190 mm	710 mm	7 1/2"	28"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apertar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ



6





480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA