





Kit 1263

JAGUAR XJ-Series, 4-dr Sedan, 02–



480R
754



480



750








THULE[®]
SWEDEN

ISO 11154-E


The diagram illustrates the importance of instructions. It features two boxes: one labeled 'THULE' with a warning symbol and a plus sign, and another labeled 'Kit XXXX' with a warning symbol and the word 'instructions'. A person is shown reading a manual, emphasizing the need to follow instructions.


Kit



3




754



750



1



X

2




JAGUAR XJ-Series, 4-dr Sedan, 02-

X

40

1



Y

2



JAGUAR XJ-Series, 4-dr Sedan, 02-

Y

39




480R



480

1



X inch/mm

2



JAGUAR XJ-Series, 4-dr Sedan, 02-


X inch

X mm

41 3/8"


1051 mm

1



Y inch/mm

2



JAGUAR XJ-Series, 4-dr Sedan, 02-

Y inch














Y mm

41"


1041 mm

4




JAGUAR XJ-Series, 4-dr Sedan, 02-



5



	X mm	Y mm	X inch	Y inch
JAGUAR XJ-Series, 4-dr Sedan, 02–	245 mm	815 mm	9 5/8"	32 1/8"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függően szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ



6



480R/754



480



750

