



Kit 1336



NISSAN Cube, 5-dr MPV, 02–

NISSAN Cube3 (Cubic), 5-dr MPV, 03–



480R
754



480





750








The diagram illustrates the assembly process. It shows a 'THULE' box, a plus sign, a box labeled 'instructions' with a 'Kit XXXX' and a table of parts, a warning triangle, and a person reading the instructions.

Kit XXXX	




					
					
					
					
					
					
					
					
					

Kit



- Box icon
- Part 624 x 2
- Part 625 x 2
- Part 171 x 4
- Control panel icon x 1




3



1




2



		X
NISSAN Cube, 5-dr MPV, 02-		64
NISSAN Cube3 (Cubic), 5-dr MPV, 03-		64

1



2



		Y
NISSAN Cube, 5-dr MPV, 02-		62,5
NISSAN Cube3 (Cubic), 5-dr MPV, 03-		62,5




480R



480

1




2



	X inch	X mm
NISSAN Cube, 5-dr MPV, 02-	50 ⁷ / ₈ "	1291 mm
NISSAN Cube3 (Cubic), 5-dr MPV, 03-	50 ⁷ / ₈ "	1291 mm

1
















2




	Y inch	Y mm
NISSAN Cube, 5-dr MPV, 02-	50 ¹ / ₄ "	1276 mm
NISSAN Cube3 (Cubic), 5-dr MPV, 03-	50 ¹ / ₄ "	1276 mm

4




NISSAN Cube, 5-dr MPV, 02–
NISSAN Cube3 (Cubic), 5-dr MPV, 03–



5



	X mm	Y mm	X inch	Y inch
NISSAN Cube, 5-dr MPV, 02-	545 mm	700 mm	21 1/2"	27 1/2"
NISSAN Cube3 (Cubic), 5-dr MPV, 03-	545 mm	700 mm	21 1/2"	27 1/2"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternadamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielvelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ



6





480R/754




480



3 Nm *




*






* $\approx 3 \text{ Nm}$








750



4 Nm





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		