




Kit 1415

CHEVROLET Matiz, 5-dr Hatchback, 05–
CHEVROLET Spark, 5-dr Hatchback, 05–



480R
754



480








750




THULE[®]
SWEDEN

ISO 11154-E



**Max.
50kg**
**Max.
110 lbs**



3





754




750

1



2




X


CHEVROLET Matiz, 5-dr Hatchback, 05-
CHEVROLET Spark, 5-dr Hatchback, 05-

21

1



2



Y

CHEVROLET Matiz, 5-dr Hatchback, 05-
CHEVROLET Spark, 5-dr Hatchback, 05-

18




480R




480

1



2



X inch


X mm

CHEVROLET Matiz, 5-dr Hatchback, 05-
CHEVROLET Spark, 5-dr Hatchback, 05-


33 ⁷/₈ "

861 mm

1



2



Y inch

Y mm














CHEVROLET Matiz, 5-dr Hatchback, 05-
CHEVROLET Spark, 5-dr Hatchback, 05-

32 ³/₄ "


831 mm

4




CHEVROLET Matiz, 5-dr Hatchback, 05–
CHEVROLET Spark, 5-dr Hatchback, 05–



5



	X mm	Y mm	X inch	Y inch
CHEVROLET Matiz, 5-dr Hatchback, 05–	250 mm	700 mm	9 ⁷ / ₈ "	27 ¹ / ₂ "
CHEVROLET Spark, 5-dr Hatchback, 05–	250 mm	700 mm	9 ⁷ / ₈ "	27 ¹ / ₂ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternadamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ



6




480R/754





480








750



4 Nm





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		544 (x4)
		596 (x6)
		588 (x8)
NA		510 (x10)
EUR		452 (x12)
ASIA		