



Kit 1438



TOYOTA Aurion, 4-dr Sedan, 06– (AUS)

TOYOTA Camry, 4-dr Sedan, 06–



**480R
754**



480








750




THULE[®]
SWEDEN



ISO 11154-E



3





754



750



1



2




TOYOTA Aurion, 4-dr Sedan, 06- (AUS)
TOYOTA Camry, 4-dr Sedan, 06-

X

38

38

1



2



TOYOTA Aurion, 4-dr Sedan, 06- (AUS)
TOYOTA Camry, 4-dr Sedan, 06-

Y

38,5

38,5




480R



480

1



2



TOYOTA Aurion, 4-dr Sedan, 06- (AUS)
TOYOTA Camry, 4-dr Sedan, 06-

X inch

X mm


40 5/8"

1031 mm

40 5/8"

1031 mm

1



2



TOYOTA Aurion, 4-dr Sedan, 06- (AUS)
TOYOTA Camry, 4-dr Sedan, 06-

Y inch

Y mm

40 3/4"

1036 mm














40 3/4"

1036 mm


4

TOYOTA Aurion, 4-dr Sedan, 06– (AUS)



TOYOTA Camry, 4-dr Sedan, 06–



5



	X mm	Y mm	X inch	Y inch
TOYOTA Aurion, 4-dr Sedan, 06– (AUS)	230 mm	680 mm	9 "	26 ³ / ₄ "
TOYOTA Camry, 4-dr Sedan, 06–	230 mm	680 mm	9 "	26 ³ / ₄ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte багаžníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ขันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		