



Kit 1478



HYUNDAI I30 CW, 5-dr Estate, 08-*

* Without railing



480R
754



480



750



THULE[®]
SWEDEN

ISO 11154-E






The diagram illustrates the assembly process. It shows a 'THULE' box, a plus sign, a box labeled 'instructions' with a 'Kit XXXX' and a table of parts, a warning triangle, and a person reading the instructions.

Kit XXXX	


					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					
					

Diagram illustrating the components for the front panel assembly:


- 958 x 4 (Corner brackets)
- 65 x 4 (Side brackets)
- Control panel (x 1)



3





754



750



1





2



HYUNDAI I30 CW, 5-dr Estate, 08–

X
32,5

1



2



HYUNDAI I30 CW, 5-dr Estate, 08–

Y
30,5




480R



480

1




2



HYUNDAI I30 CW, 5-dr Estate, 08–

X inch X mm
38 ³/₈ " 976 mm

1



2
















HYUNDAI I30 CW, 5-dr Estate, 08–


Y inch Y mm
37 ⁵/₈ " 956 mm

4




HYUNDAI I30 CW, 5-dr Estate, 08–



5



	X mm	Y mm	X inch	Y inch
HYUNDAI I30 CW, 5-dr Estate, 08–	450 mm	740 mm	17 ³ / ₄ "	29 ¹ / ₈ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apertar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól fűggetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ






6













480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA