







Kit 1515


TOYOTA Corolla, 4-dr Sedan, 09– (NA)



				
  x2  x2  x2  x4	  x2	  x2  x2  x4  x4	  x2  x2	  x2

Kit

1




480R/754



480



750



2



480R/754














480




750



+



3




754



750



1



2




TOYOTA Corolla, 4-dr Sedan, 09- (NA)

X

33

1



2



TOYOTA Corolla, 4-dr Sedan, 09- (NA)

Y

30,5




480R




480

1



2



TOYOTA Corolla, 4-dr Sedan, 09- (NA)


X inch

38 ⁵/₈ "


X mm

980 mm

1



2



TOYOTA Corolla, 4-dr Sedan, 09- (NA)

Y inch














37 ⁵/₈ "

Y mm


955 mm

4



TOYOTA Corolla, 4-dr Sedan, 09- (NA)



5



	X mm	Y mm	X inch	Y inch
TOYOTA Corolla, 4-dr Sedan, 09– (NA)	255 mm	686 mm	10 "	27 "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apertar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťte bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφίγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ



6






480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA