




Kit 1650

NISSAN Serena, 5-dr Van, 10–


SUZUKI Landy, 5-dr Van, 10–



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
SWEDEN

ISO 11154-E

754 Rapid System

480R Rapid Traverse (North America)

754 Rapid System

480R Rapid Traverse (North America)

754 Rapid System



480R Rapid Traverse (North America)

754 Rapid System


480R Rapid Traverse (North America)

754 Rapid System

480R Rapid Traverse (North America)

Europe		North America	
			
			
			
			



1





2





754 Rapid System
480R Rapid Traverse
(North America)




x4





10 mm



x4





10 mm



x4




480 Traverse
(North America)




x4

3



754 Rapid System




X

NISSAN Serena, 5-dr Van, 10–

42

SUZUKI Landy, 5-dr Van, 10–

42



Y

NISSAN Serena, 5-dr Van, 10–

42,5

SUZUKI Landy, 5-dr Van, 10–

42,5

3




480R Rapid Traverse



480 Traverse



(North America)



X inch

X mm

NISSAN Serena, 5-dr Van, 10–


42 1/8"

1071 mm

SUZUKI Landy, 5-dr Van, 10–

42 1/8"

1071 mm



Y inch

Y mm

NISSAN Serena, 5-dr Van, 10–

42 3/8"


1076 mm

SUZUKI Landy, 5-dr Van, 10–

42 3/8"



1076 mm

4




5


NISSAN Serena, 5-dr Van, 10–
SUZUKI Landy, 5-dr Van, 10–




6





i







A




B



	X mm	Y mm	X inch	Y inch
NISSAN Serena, 5-dr Van, 10-	760 mm	685 mm	30"	27"
SUZUKI Landy, 5-dr Van, 10-	760 mm	685 mm	30"	27"







7





GB/US	Tighten alternately
D	Die Schrauben abwechselnd anziehen
F	Serrer alternativement chaque côté
NL	Afwisselend aan de linker- en de rechterkant aandraaien
I	Alternare il serraggio delle viti
E	Apretar alternativamente
PT	Aperte alternadamente
S	Dra åt växelvis
FIN	Kierrä vuorotellen
EST	Pinguldage vaheldumisi
LAT	Pielvelciet pamišus
LIT	Užsukinėkite pakaitomis
PL	Śruby dokręcaj naprzemiennie
RU	Затягивайте попеременно

CZ	Pokrétla багаžníka dokręcaj dokręcaj naprzemiennie.
SK	Dofahujte striedavo
SLO	Privijajte izmenično.
HR	Naizmenično zategnite
HU	Egymástól függetlenül szorítandó
GR	Σφιγγετε εναλλάξ
TR	Dönüşümlü sıkın

中文	交替拧紧
한국어	번갈아 가며 조이십시오.
日本語	交互に締め付けてください。
ไทย	ขันในแบบสลับ




≈ 3 Nm





8



x1
17 mm





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA **510** (x10)

EUR **452** (x12)

ASIA