




Kit 1678


CHRYSLER Ypsilon, 5-dr Hatchback, 11-
LANCIA Ypsilon, 5-dr Hatchback, 11-



754 Rapid System
480R Rapid Traverse (North America)




480 Traverse (North America)




754 Rapid System
480R Rapid Traverse (North America)

480 Traverse (North America)



1






2






754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4



480 Traverse
(North America)




x4


3



754 Rapid System



	X
CHRYSLER Ypsilon , 5-dr Hatchback, 11-	39
LANCIA Ypsilon , 5-dr Hatchback, 11-	39



	Y
CHRYSLER Ypsilon , 5-dr Hatchback, 11-	33,5
LANCIA Ypsilon , 5-dr Hatchback, 11-	33,5

3




480R Rapid Traverse




480 Traverse

(North America)






	X inch	X mm
CHRYSLER Ypsilon , 5-dr Hatchback, 11-	41 "	1041 mm
LANCIA Ypsilon , 5-dr Hatchback, 11-	41 "	1041 mm




	Y inch	Y mm
CHRYSLER Ypsilon , 5-dr Hatchback, 11-	38 ⁷/₈ "	986 mm
LANCIA Ypsilon , 5-dr Hatchback, 11-	38 ⁷/₈ "	986 mm

4




5**CHRYSLER Ypsilon, 5-dr Hatchback, 11-
LANCIA Ypsilon, 5-dr Hatchback, 11-**


6





i




A



B



CHRYSLER Ypsilon, 5-dr Hatchback, 11-	115 mm	865 mm	4 1/2"	34"
LANCIA Ypsilon, 5-dr Hatchback, 11-	115 mm	865 mm	4 1/2"	34"



7



GB/US	Tighten alternately
D	Die Schrauben abwechselnd anziehen
F	Serrer alternativement chaque côté
NL	Afwisselend aan de linker- en de rechterkant aandraaien
I	Alternare il serraggio delle viti
E	Apertar alternativamente
PT	Aperte alternadamente
S	Dra åt växelvis
FIN	Kierrä vuorotellen
EST	Pinguldage vaheldumisi
LAT	Pielveiciet pamišus
LIT	Užsukinėkite pakaitomis
PL	Śruby dokręcaj naprzemiennie
RU	Загрягивайте попеременно


CZ	Pokręřta багаžnika dokręřcaj dokręřcaj naprzemiennie.
SK	Dofahajte striedavo
SLO	Privijajte izmenično.
HR	Naizmjenično zategnite
HU	Egymástól függetlenül szorítandó
GR	Σφιγίγτες εναλλάξ
TR	Dönüşümlü sıkın

中文 交替拧紧



한국어 번갈아 가며 조이십시오.



日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ



8





THULE
SWEDEN
**ONE
KEY
SYSTEM**



		(x4)
		(x6)
		(x8)
NA		(x10)
EUR		(x12)
ASIA		



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com
customer.service@thule.com

www.thule.com