





Kit 1426

LEXUS IS (MK II), 4-dr Sedan, 05-



480R
754



480



750



xx kg
 xx lbs

7 kg
 15,4 lbs

Max.
60 kg
Max.
132 lbs

80 km/h
 50 Mph
 130 km/h
 80 Mph
 40 km/h
 25 Mph
 km/h
 Mph

THULE

Kit XXXX
 instructions

x1

x4

x4

x4
 x4

480R/754

x1

x4

x4

x4

480

x1

x4

x4

750

x2 x2 x2 x4	x2	x2 x2 x4 x4	x2 x2	x2
----------------------	----	----------------------	----------	----

853 x2






849 x2



204 x2

206 x2


x1

Kit










	X
LEXUS IS (MK II), 4-dr Sedan, 05-	30



	Y
LEXUS IS (MK II), 4-dr Sedan, 05-	28.5



	X inch	X mm
LEXUS IS (MK II), 4-dr Sedan, 05-	37 1/2"	951 mm



	Y inch	Y mm
LEXUS IS (MK II), 4-dr Sedan, 05-	36 7/8"	936 mm



4

LEXUS IS (MK II), 4-dr Sedan, 05-

204



849



206



849



206















853




204






853



5



	X mm	Y mm	X inch	Y inch
LEXUS IS (MK II), 4-dr Sedan, 05-	270 mm	620 mm	10 ⁵ / ₈ "	24 ³ / ₈ "



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielieciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันโนแบบสลับ



6




480R/754




480



3 Nm *




*




* ≈ 3 Nm



750



4 Nm




i




1




2




i



1




2




i





1



2





THULE
SWEDEN
**ONE
KEY
SYSTEM**



- 544 (x4)
- 596 (x6)
- 588 (x8)
- NA 510 (x10)
- EUR 452 (x12)
- ASIA



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com
customer.service@thule.com

www.thule.com